

SAFE AND EASY BONDING

Apply the adhesive, press on and you're done. The KEUCO adhesive set for AVENO accessories impresses with its very easy application.



The adhesive set contains a cleaning cloth and an abrasive cloth. The brushed surface helps the adhesive to stick even better.



Clean the adhesive surface on the product before applying the adhesive.



Clean the bonding surface on the wall thoroughly before bonding.



After finalising the product's position, mark the mounting points.



Press the complete contents of the adhesive stick onto the mix pad_and mix with the spatula until you achieve an even mixture and colour.



Then use the spatula to apply the adhesive directly to the accessory's wall connection.



Press onto the wall in the desired position. Allow the adhesive to cure for at least four hours using the cardboard to secure it.



Finally, attach the product, secure with the grub screw and the assembly process is complete - all without any drilling.